AB

Modular Type Lubricator AL Series

Lubricator AL Series	Model	Port size	Option
	AL10-A	M5 x 0.8	
	AL20-A	1/8, 1/4	
	AL30-A	1/4, 3/8	
As de since.	AL40-A	1/4, 3/8, 1/2	Bracket (Except AL10-A)
One II	AL40-06-A	3/4	
	AL50-A	3/4, 1	
Pages 83 to 90	AL60-A	1	

Lubricator

AL10-A to AL60-A

Symbol










How to Order

AL20-A

AL40-A



- Option/Semi-standard: Select one each for a to d.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

Example) AL30-03B-3RW-A

	_	_						1			
				Symbol	Description			Body	size		
						10	20	30	40	50	60
					Metric thread (M5)	•	_	_	_	_	_
2		Dina	e thread type		Rc	_	•	•	•	•	•
4		ripe	e tilleau type	N	NPT		•	•	•	•	•
				F	G	_	•	•	•	•	•
				+							
				M5	M5 x 0.8		_	_	_	_	_
				01	1/8	_	•	_	_	_	_
				02	1/4	_	•	•	•	_	_
3			Port size	03	3/8		_	•	•	_	
_				04	1/2	_	_	_	•	_	_
				06	3/4		_	_	•	•	_
				10	1	_	_	_	_	•	•
				+				•	•	•	
		O-4:-	(Matim.a.)	_	Without mounting option	•	•	•	•	•	•
4	'	Optic	on (Mounting)	B*1	With bracket		•	•	•	•	•
				+			'				
				_	Polycarbonate bowl	•	•	•	•	•	•
				2	Metal bowl	•	•	•	•	•	•
			Bowl *2 *3	6	Nylon bowl	•	•	•	•	•	•
		а	BOWL	8	Metal bowl with level gauge	_	_	•	•	•	•
				С	With bowl guard	_	•	<u>*</u> *4	*4	*4	<u>*</u> *4
				6C	With bowl guard (Nylon bowl)	_	•	—* ⁵	<u></u> *5	<u></u> *5	<u></u> *5
	laro			+							
	and			_	Without drain cock		•	•	•	•	•
6	i-st	b	Lubricant	3	With drain cock	•	•	•	•	•	•
	Semi-standard		exhaust port	3W*6	Drain cock with barb fitting		_	•	•	•	•
	S			+	5			L			
				_	Flow direction: Left to right	•	•	•	•	•	
		С	Flow direction	R	Flow direction: Right to left	•	•	•	•	•	•
				+	5			1			
			_	_	Name plate and caution plate: MPa		•		•	•	
		d	Pressure unit	Z *7	Name plate and caution plate: psi, °F	O*8	O*8	O*8	O*8	O*8	O*8
					The second place best .)))	

- *1 Option is not assembled and supplied loose at the time of shipment.
- *2 Refer to chemical data on page 86 for chemical resistance of the bowl.
- *3 Refer to page 89 for 1000 cm³ tanks.
- *4 A bowl guard is provided as standard equipment (polycarbonate).
- *5 A bowl guard is provided as standard equipment (nylon).
- *6 The combination of metal bowl: 2 and 8 is not available.
- *7 For pipe thread type: M5, NPT.
- *8 O: For pipe thread type: M5, NPT only



Lubricator AL10-A to AL60-A Series

Standard Specifications

Model	AL10-A	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A
Port size	M5 x 0.8	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1
Fluid				Air			
Ambient and fluid temperature			-5 to 6	0 °C (with no fre	ezing)		
Proof pressure				1.5 MPa			
Maximum operating pressure				1.0 MPa			
Minimum duinning floures			1/4: 30	1/4: 30			
Minimum dripping flow rate [I/min (ANR)] *1	4 15			3/8: 40	50	190	220
[//IIIII (ANA)]			3/8: 40	1/2: 50			
Oil capacity [cm³]	7	25	55		13	35	
Recommended lubricant			Class 1	turbine oil (ISO	VG32)		
Bowl material				Polycarbonate			
Bowl guard	_	Semi-standard (Steel)		Stan	dard (Polycarbor	nate)	
Weight [kg]			0.38	0.43	0.94	1.09	

^{*1 ·} The flow rate is 5 drops or greater/min under the following conditions: Inlet pressure of 0.5 MPa; Class 1 turbine oil (ISO VG32); Temperature at 20 °C; Oil adjustment valve fully open.

Option/Part No.

Optional specifications		Model											
	AL10-A	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A						
Bracket assembly *1	_	AF22P-050AS	AF32P-050AS	AF42P-050AS	AF42P-070AS	AF52P	-050AS						

^{*1} Assembly of a bracket and 2 mounting screws

Bowl Assembly/Part No.

David	Lubricant					Model						
Bowl material	Lubricant exhaust port	Other	AL10-A	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A			
	Without drain cock	_	C1SL-A	C2SL-A	_		_					
	Without drain cock	With bowl guard	_	C2SL-C-A	C3SL-A	C4SL-A						
Polycarbonate	With drain cock	_	C1SL-3-A	C2SL-3-A	_		_	_				
	With drain cock	With bowl guard	_	C2SL-3C-A	C3SL-3-A	C4SL-3-A						
	Drain cock with barb fitting	With bowl guard		_	C3SL-3W-A	C4SL-3W-A						
	Without drain cock	_	C1SL-6-A	C2SL-6-A	_	_						
	Without drain cock	With bowl guard		C2SL-6C-A	C3SL-6-A	C4SL-6-A						
Nylon	With drain cock	_	C1SL-36-A	C2SL-36-A	_		_	_				
	With drain cock	With bowl guard	_	C2SL-36C-A	C3SL-36-A		C4SL	-36-A				
	Drain cock with barb fitting	With bowl guard	_	_	C3SL-36W-A		C4SL-	36W-A				
	Without drain cock	_	C1SL-2-A	C2SL-2-A	C3SL-2-A		C4SI	2-A				
Metal	Without drain Cock	With level gauge	_	_	C3LL-8-A		C4LL	8-A				
ivietal	With drain cock	_	C1SL-23-A	C2SL-23-A	C3SL-23-A	C4SL-23-A						
	With drain COCK	With level gauge	_	_	C3LL-38-A		C4LL	-38-A				


 $[\]cdot$ Bowl seal is included for the AL20-A to AL60-A.


For a circuit that repeatedly turns ON and OFF on the outlet side, make the adjustment so that the average air consumption per minute becomes the minimum dripping flow rate or more.


[·] Please consult with SMC separately for psi and °F unit display specifications.


AL10-A to AL60-A Series


Flow Rate Characteristics (Representative values)


















Working Principle: AL10



A portion of the air introduced from the IN side pressurises the lubricant inside the bowl. The remainder of the air passes through the needle ③, and flows to the OUT side. The differential pressure between the inside of the bowl and the inside of the sight dome ②, causes the lubricant inside the bowl into the oil passage ⑥. The lubricant drips from the dripping tube ⑥, and lubricates the OUT side. The amount of lubricant is adjusted by the needle ⑨ on the front face. Turning the needle clockwise increases the amount of the lubricant, and turning it counterclockwise until fully open shuts off the lubricant. The needle on the side that is not used should be left fully open.



Selection

∕!**∖Warnin**q

- 1. Do not introduce air from the outlet side as this can damage the bumper.
- 2. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

Type	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda Sodium sulfide Potassium nitrate Sulfate of soda Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride Methylene chloride Benzene Toluene Paint thinner Acetone Methyl ethyl ketone Cyclohexane Ethyl alcohol IPA Methyl alcohol Gasoline Kerosene Phthalic acid dimethyl Phthalic acid dimethyl Acetic acid Methyl ether Ethyl ether Methyl amino Thread-lock fluid Seawater	Application examples	Mate	erial
Type	Chemical name	Application examples	Polycarbonate	Nylor
Acid	Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×
Alkaline	Potash Calcium hydroxide (Slack lime) Ammonia water	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0
Inorganic salts	Potassium nitrate	_	×	Δ
Chlorine solvents	Chloroform Ethylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ
Aromatic series	Toluene	Coatings Dry cleaning	×	Δ
Ketone	Methyl ethyl ketone	Photographic film Dry cleaning Textile industries	×	×
Alcohol	IPA	Antifreeze Adhesives	Δ	×
Oil		_	×	0
Ester	Phthalic acid diethyl	Synthetic oil Anti-rust additives	×	0
Ether		Brake oil additives	×	0
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×
Others		-	×	Δ

When the above factors are present, or there is some doubt, use a metal bowl for safety.

Selection

∕∴Caution

1. Use a check valve (AKM series) to prevent back flow of the lubricant when redirecting the air flow before the lubricator.

Maintenance

∕!\Warning

- 1. For the AL10-A/AL20-A, replenish the lubricant after releasing the inlet pressure. Lubrication cannot take place under a pressurised condition.
- 2. Adjustment of the oil regulating valve for models from the AL20-A to AL60-A should be carried out manually. Turning it counterclockwise increases the dripping amount, and turning it clockwise reduces the dripping amount. The use of tools etc. can result in damage to the unit. From the fully closed position, three rotations will bring it to the fully open position. Do not rotate it any further than this. Note that the numbered scale markings are guidelines for adjusting the position, and not indicators of the dripping amount.

∕!\Caution

1. Check the dripping amount once a day. Drip failure can cause damage to the components that need lubrication.

Mounting/Adjustment

∕!\Caution

1. When the bowl is installed on the AL30-A to AL60-A, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.







AL10-A to AL60-A Series

Construction

AL10-A




AL20-A






AL30-A/AL40-A







Component Parts

No.	Description	Material	Model	Colour
	Body	Zinc die-cast	AL10-A	White
'	Войу	Aluminium die-cast	AL20-A to AL60-A	vviille
8	Housing	Aluminium die-cast	AL50-A/AL60-A	White


Replacement Parts

пор	lacement i arts											
No.	Description	Material				Part no.						
INO.	Description	Material	AL10-A	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A			
2	Sight dome assembly	Polycarbonate	AL10P-080AS			AL20P	-080AS					
3	Lubrication plug assembly	_	_	AL22P-060AS	AL32P-060AS	AL42P-060AS						
4	Bumper retainer assembly	_	_	AL20P-030AS	AL30P-030AS	AL40P	-030AS	AL50P-030AS	AL60P-030AS			
5	Bumper (assembly)	Synthetic resin	_	AL20P-040S	AL30P-040S	AL40F	P-040S	AL50P-040AS	AL60P-040AS			
6	Bowl seal	NBR	C1SFP-260S	C2SFP-260S	C32FP-260S		C42FP-260S					
7	Bowl assembly *1	Polycarbonate	C1SL-A	C2SL-A	C3SL-A		C45	SL-A				

^{*1 ·} Bowl seal is included for the AL20-A to AL60-A. Please consult with SMC separately for psi and °F unit display specifications. · Bowl assembly for the AL30-A to AL60-A models comes with a bowl guard (Material: Polycarbonate).



Dimensions



Applicable model		AL10-A/AL20-A		AL30-A to AL60-A
Optional/Semi-standard specifications	With drain cock	Metal bowl	Metal bowl with drain cock	Metal bowl
Dimensions	8	a	B B	

Applicable model			AL30-A to AL60-	Α	
Optional/Semi-standard specifications	With drain cock	Metal bowl with level gauge	Metal bowl with drain cock	Metal bowl with level gauge, with drain cock	Drain cock with barb fitting
Dimensions	B	В	B	B	Barb fitting applicable tubing: T0604

											Optio	onal sp	ecifica	tion	S		Semi-standard specifications					
Model		(Standard	d speci	ficatior	ıs			Bracket mount						With drain cock	With barb fitting	Metal bowl	Metal bowl with drain cock	Metal bowl with level gauge	Metal bowl with level gauge, with drain cock		
	Р	Α	В	С	D	Е	G	J	M	M N Q R S T U V						<	В	В	В	В	В	В
AL10-A	M5 x 0.8	25	51.5	25.5	12.5	_	35	12.5	_	_	_	_	_	_	_	_	59.9	_	56.3	59.3	_	
AL20-A	1/8, 1/4	40	79.3	35.9	20	_	60	20	30	27	22	5.4	8.4	40	2.3	28	87.7	_	84.5	87.5	_	_
AL30-A	1/4, 3/8	53	104.1	38.1	26.7	30	80	26.7	41	35	23	6.5	13	53	2.3	30	115.1	123.6	104.1	117.6	124.1	137.6
AL40-A	1/4, 3/8, 1/2	70	136.1	39.8	35.5	38.4	110	35.5	50	52	26	8.5	12.5	70	2.3	35	147.1	155.6	136.1	149.6	156.1	169.6
AL40-06-A	3/4	75	138.1	37.8	35.5	38.4	110	35.5	50	52	25	8.5	12.5	70	2.3	34	149.1	157.6	138.1	151.6	158.1	171.6
AL50-A	3/4, 1	90	209.1	41.2	45	_	110	45	70	66	35	11	13	90	3.2	47	220.1	228.6	209.1	222.6	229.1	246.2
AL60-A	1	95	223.1	44.7	47.5	_	110	47.5	70	66	35	11	13	90	3.2	47	234.1	242.6	223.1	236.6	243.1	256.6